### Work Order ID 55137

January 7, 2010 8:19:24 AM



Page 1

DSI 9420-013 Accept Item ID: Setup Start **Revision ID:** В Stop Item Name: Run-On Landing Wearplate Upgrade, High Gear **Start Date:** 1/07/10 Start Qty: 2.00 **Cust Item ID:** Required Date: 1/08/10 Req'd Qty: 2.00 **Customer:** Reference: Run Start Process Plan: Date: Tooling: Approvals: Date: Stop SPC (Y/N): Date: Date: Sequence ID/ **Operation** Set Up/ Reject Draw Draw Plan Accept Reject Insp. Work Center ID Description Qty Qty **Run Hours** Number Rev. Code Number Stamp Draw Nbr **Revision Nbr** В DSI 9420 100 0.00 Bt 10-1-07 Memo Photocopy bluefile &type labels per PPP DSI 9420-013 **Document Control** CHG001 110 Pick Kit 0.00 Packaging 0.00 Memo Packaging

120

QC

Memo

QC4-100% Inspect kits for completeness

2) Siolovos

**Quality Control** 

0.00

0.00

### Work Order ID 55137

В

January 7, 2010 8:19:24 AM



Page 2

Item ID:

DSI 9420-013

Accept

Setup Start



**Revision ID:** Item Name:

Run-On Landing Wearplate Upgrade, High Gear

Stop

**Start Date:** 

1/07/10

Start Qty: 2.00

Req'd Qty: 2.00



**Cust Item ID: Customer:** 

Reference:

Approvals:

Process Plan:

Date:

**Tooling:** 

Date:

Run Start

Reject

Qty



Required Date: 1/08/10

QC:

Date:\_\_\_\_\_

SPC (Y/N):

Date:

Draw

Rev.

Plan

Code

Stop



Number Stamp

Reject

Sequence ID/ **Work Center ID** 

130

Packaging Packaging

Description

Operation

Set Up/ **Run Hours** 

0.00

0.00

Memo Identify and pack for shipping as per PPP DSI 9420-013

Location:

PPP rev:

Draw

Number

Accept

Qty

Insp.

140

QC21- Final Inspection - Work Order Release

0.00



**Quality Control** 

QC

Memo

0.00

W 12-01-08

### **Picklist Print**

January 7, 2010 8:19:22 AM

Work Order ID: 55137

Parent Item:

DSI 9420-013



Parent Item Name: Run-On Landing Wearplate Upgrade, High Gear

**Start Date: 1/07/10** 

Required Date: 1/08/10

Comments:								S	start Qty: 2.00		Required Qty:	2.00
Component Item ID/ Item Name	Replacement Item ID	Mfg/ Purch	Bin Item	Primary Location	Last Location	Route Seq ID	Unit of Measure	Qty on Hand	Remaining Qty To Pick	Qty Issued	Date Issued	Status
AN3-37A + 7 2 Bolt		Purchased	No	· · · · · · · · · · · · · · · · · · ·		110	Each	719.0000	14.0000	0-1-	۷	ρ
				<u>Warehoi</u> Loca		Loc	<u>Oty</u>	Loc Code				

		<del> </del>	230t Cout			
<b>Location</b>						
Main Warehouse				1		
ST		719		i		
105425		219		i	19	
111668		500			<del></del> -	
	110	Each	998.0000	14.0000		0
					10-1-7	$\leq (l (x))$



No

Purchased

Warehouse Location	Loc Oty	Loc Code	
Main Warehouse			
ST	998		
105442	8		
109059	2		
109840	23		
110139	2		
110985	202		
111279	5		
111668	48		
112314	78		
112369	22		
113149	608		14.

January 7, 2010 8:19:22 AM

Work Order ID: 55137

DSI 9420-013

Parent Item:

Parent Item Name: Run-On Landing Wearplate Upgrade, High Gear

**Start Date: 1/07/10** 

Required Date: 1/08/10

Comments:								S	Start Qty: 2.00		Required Qty	: 2.00
Component Item ID/ Item Name	Replacement Item ID	Mfg/ Purch	Bin Item	Primary Location	Last Location	Route Seq ID	Unit of Measure	Qty on Hand	Remaining Qty To Pick	Qty Issued	Date Issued	Status
D2649 + 2 Cross Bolt Spacer		Manufactured	No			110	Each	202.0000	4.0000	10-1-7	S	(34)
2				Wareho	<u>use</u>	Loc	Qty	Loc Code				
				Loca	ation							

Warehouse	Loc Oty	<u>′</u>	Loc Code			
<b>Location</b>						
Main Warehouse						
LG	8	33				
51529	8	33				
Main Warehouse						
ST	11	9				
36013 (47112 48271	11	5 0 4			4	
402/1		Each	0.0000	2.0000	D 88 12 A	(
					1222 138	10-1-851

Wearplate Assembly Fwd, High Gear D3805-047 1

Manufactured

Manufactured

No

No

0.0000

110

Each

## **Picklist Print**

January 7, 2010 8:19:22 AM

Work Order ID: 55137

Parent Item:

DSI 9420-013



ST

111650

Parent Item Name: Run-On Landing Wearplate Upgrade, High Gear

**Start Date: 1/07/10** 

Required Date: 1/08/10

Page 3

Comments:									Start Qty: 2.00	)	Required Qty: 2	2.00
Component Item ID/ Item Name	Replacement Item ID	Mfg/ Purch	Bin Item	Primary Location	Last Location	Route Seq ID	Unit of Measure	Qty on Hand	Remaining Qty To Pick	Qty Issued	Date Issued	Status
D3873-1		Manufactured	No			110	Each	39.0000	28.0000	10-1-7	5(	)
2 Busining				Warehou Loca		Loc	<u>Oty</u>	Loc Code	1		1	
				Main Wa	53443		25 25		_	14		
M521042-3	I IIII II III III	Purchased	No	STI	50479	110	14 14 Each	100.0000	J 100(1) (80)	Ч Мигэз/ч	4 10-1-	7 W 5
USE MS21042L3				Warehoo Loca Main Wa	<u>ition</u>	Loc	<u>Qty</u>	Loc Code		_		

100

100

January 7, 2010 8:19:22 AM

**Shop Packet Print** 

Page 3

# REFERENCE ONLY



#### 9.0 DSI 9420-011/-013 RUN-ON LANDING WEARPLATE UPGRADE KIT INSTALLATION

- 9.0.1 Remove the D206-642-111/-112/-211/-212/-213/-214 Skidtube per Section 32.1 of ICA-D206-642 Rev. 1 or earlier. Remove existing wearplates. Inspect the bottom of the tube for damage and touch up finish per Section 5.2.11 of ICA-D206-642 Rev. 1 or earlier. Plug existing wearplate inserts using Sikaflex-241/-291 or Proseal 890.
- 9.0.2 Remove qty(10) D2651-1 Plugs where the AN3 Bolts will be inserted to install the run-on landing wearplate assemblies. Refer to Figure 2.
- 9.0.3 Locate and temporarily install the Wearplate Assemblies per Figure 1. On both sides of the skidtube, transfer drill qty(2) Ø0.375" holes from the Wearplate Assembly to the Skidtubes as shown in Figure 2. Countersink the holes on both sides to Ø0.450" X 45°. Deburr.
- 9.0.4 Install D2649 Spacer per Sections A-A or B-B using Magnobond 6398. Grind flush as required. Allow Magnobond to cure per manufacturer's instructions.
- 9.0.5 Install the D3805-XXX Wearplate Assemblies using the qty(7) AN3-37A bolts and associated fasteners, as shown in Figure 1 of this service instruction. Torque fasteners to 15-25 in-lb (1.7-2.8 N-m).
- 9.0.6 Reinstall the Skidtube on the aircraft per Section 32.2 of ICA-D206-642 Rev.1 or earlier.
- 9.0.7 Update weight and balance information per Section 6.0 of this service instruction. Customers upgrading D206-642-111/-112 Skidtubes should adopt Weight & Balance of D206-642-113/-114 Skidtubes and customers upgrading D206-642-211/-212/-213/-214 Skidtubes should adopt Weight & Balance of D206-642-215/-216/-217/-218 Skidtubes.

#### 10.0 DSI 9420-011/-013 PARTS LIST

Qty -011	/ Qty	Part Number	Description
Х		DSI 9420-011	RUN-ON LANDING WEARPLATE UPGRADE KIT, LOW GEAR
	Х	DSI 9420-013	RUN-ON LANDING WEARPLATE UPGRADE KIT, HIGH GEAR
2	/2	D2649	SPACER
1		-D3805-041 -	FWD WEARPLATE ASSY
1		D3807-1	* GASKET <sup>(1)</sup>
	1/	D3805-043	FWD WEARPLATE ASSY
	1	D3807-3	* GASKET <sup>(2)</sup>
1		D3805-045	AFT WEARPLATE ASSY
1		D3807-5	* GASKET (3)
-	1	D3805-047	AFT WEARPLATE ASSY
		D3807-7	* GASKET (4)
14	/ 14	D3873-1 /	BUSHING
	7		
7	<u> </u>	AN3-37A	≠BOLT
7	1.7	AN960JD10 🐪 💷	WASHER
7	1 7	MS21042-3 F	NUT (OR MS21042L3)

NOTES:

- (1) DENOTES THAT PART IS INCLUDED WITH D3805-041 ASSEMBLY ABOVE
- (2) DENOTES THAT PART IS INCLUDED WITH D3805-043 ASSEMBLY ABOVE
- (3) DENOTES THAT PART IS INCLUDED WITH D3805-045 ASSEMBLY ABOVE
- (4) DENOTES THAT PART IS INCLUDED WITH D3805-047 ASSEMBLY ABOVE

NEW Ø0.375 THRU HOLE



NEW Ø0.375 THRU HOLE



KEEP D2651-1 PLUG INSTALLED 3 PL (D206-642-111/-112) 4 PL (D206-642-211/-212/-213/-214)

# FIGURE 2: D206-642-111/-112/-211/-212/-213/-214 SKIDTUBE MOD

(D206-642-111/-112 SHOWN - D206-642-211/-212/-213/-214 SIMILAR)

DESIGN	97	DART AEROSPACE USA, INC PORT HADLOCK, WA					
DRAWN	AJS						
CHECKED	4	DRAWING NO.	REV. B				
MFG. APPR.	N/A	DSI 9420	SHEET 6 OF 6				
APPROVED	-11	TITLE	SCALE				
DE APPR.		SKIDTUBE INSTALLATION	NTS				
DATE 09.0	3.25	COPYRIGHT © 2008 BY DART AEROSPACE USA, INC THIS DOCUMENT IS PRIVATE AND CONFIDENTIAL AND IS SUPPLIED ON THE EXPRESS CONDITION THAT IT IS NOT TO BE USED FOR ANY PURPOSE OR COMED OR COMMANICATED TO ANY OTHER PERSON WITHOUT WITHOUT WITHOUT WITH PERMISSION FROM DATA PERSONS USA INC.					